

Installation

Plug the VHS-K10-72 into the Krone LSA* disconnect block.

Make sure the VHS-K10-230 is inserted fully into the block. The edge of the plastic cover should be level with the front of the block.

The earth connection occurs when the spring clip on each end of the VHS engages the Krone* frame upon insertion.

If the Krone Profil* block is being used, insert the spring clip onto each end of the Krone* Block to allow earth connection to occur.

The frame must be properly bonded to the main electrical earth.

